

Manual | EN

TS6280

TwinCAT 2 Ethernet/IP Slave

Supplement | Communication



Table of contents

1 Foreword	5
1.1 Notes on the documentation	5
1.2 For your safety	6
1.3 Notes on information security.....	7
2 Configuration	8
3 Configuration TwinCAT 2.11 R3	20
4 Error Codes	32

1 Foreword

1.1 Notes on the documentation

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning the components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents:

EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702

with corresponding applications or registrations in various other countries.



EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

1.2 For your safety

Safety regulations

Read the following explanations for your safety.

Always observe and follow product-specific safety instructions, which you may find at the appropriate places in this document.

Exclusion of liability

All the components are supplied in particular hardware and software configurations which are appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

Personnel qualification

This description is only intended for trained specialists in control, automation, and drive technology who are familiar with the applicable national standards.

Signal words

The signal words used in the documentation are classified below. In order to prevent injury and damage to persons and property, read and follow the safety and warning notices.

Personal injury warnings

DANGER

Hazard with high risk of death or serious injury.

WARNING

Hazard with medium risk of death or serious injury.

CAUTION

There is a low-risk hazard that could result in medium or minor injury.

Warning of damage to property or environment

NOTICE

The environment, equipment, or data may be damaged.

Information on handling the product



This information includes, for example:
recommendations for action, assistance or further information on the product.

1.3 Notes on information security

The products of Beckhoff Automation GmbH & Co. KG (Beckhoff), insofar as they can be accessed online, are equipped with security functions that support the secure operation of plants, systems, machines and networks. Despite the security functions, the creation, implementation and constant updating of a holistic security concept for the operation are necessary to protect the respective plant, system, machine and networks against cyber threats. The products sold by Beckhoff are only part of the overall security concept. The customer is responsible for preventing unauthorized access by third parties to its equipment, systems, machines and networks. The latter should be connected to the corporate network or the Internet only if appropriate protective measures have been set up.

In addition, the recommendations from Beckhoff regarding appropriate protective measures should be observed. Further information regarding information security and industrial security can be found in our <https://www.beckhoff.com/secguide>.

Beckhoff products and solutions undergo continuous further development. This also applies to security functions. In light of this continuous further development, Beckhoff expressly recommends that the products are kept up to date at all times and that updates are installed for the products once they have been made available. Using outdated or unsupported product versions can increase the risk of cyber threats.

To stay informed about information security for Beckhoff products, subscribe to the RSS feed at <https://www.beckhoff.com/secinfo>.

2 Configuration

The TwinCAT EtherNet/IP Slave enables EtherNet/IP Connectivity to the TwinCAT System.

Requirements:

- **Win2000 / Windows XP:** TwinCAT 2.10 Build 1309 or newer
- **Windows CE:** Windows CE 5.0 (Beckhoff Windows CE image Build version 2.16) or newer
- License Key for TwinCAT EtherNet/IP Slave Supplement product
- Intel PRO Network Interface Card (Ethernet Controller Intel 825X)

Installation

Download TwinCAT Supplement Installer for EtherNet/IP connectivity.

Operating System:

Windows 2000 / XP/ Windows XP Embedded:
[TwinCAT Supplement System](#)

Windows CE:
[TwinCAT Supplement System](#)

Run the Installer on your programming PC and follow its instructions.

If the target operating system is Windows 2000 / Windows XP or Windows XP Embedded, the TwinCAT EtherNet/IP-Slave is now ready for Start-Up (go on with chapter "Start-Up").

If the target operating system is Windows CE, please follow the instructions below:

- The folder `..\TwinCAT\CE\TwinCAT EtherNetIP Slave CE\Install\ARM` contains a Cabinet-File (CAB file) for ARM-based CE runtime systems (e.g. CX9001, CX9010, CP66xx,...).
The folder `..\TwinCAT\CE\TwinCAT EtherNetIP Slave CE\Install\X86` contains a Cabinet-File for X86-based CE runtime systems (e.g. CX1000, CX1020, CP77xx, CP62xx, CP72xx, C69xx,...)
- Copy the file: `TcEtherNetIP_S_Ce.XXXXX.CAB` into a folder on the CE runtime system.
- On the CE system: Please install (double-click the CAB file) the CE components.
- **IMPORTANT:** Please suspend the CE device once after installation via "Start-> Suspend"!


Start-Up

General information

- At the moment, the TwinCAT EtherNet/IP Slave does only support static IP-Address configurations. When the TwinCAT EtherNet/IP Slave configuration is being activated, the System is only going to start up in RUN-Mode if the actual address settings match the stored configuration.

First Steps


1. Start the TwinCAT System Manager, create a new project and use the context menu after a mouse-click on "I/O Devices", to append a device in the I/O-Configuration



2. Choose "Real-Time Ethernet" from the Ethernet device type section as shown below




- On the newly added "Real-Time Ethernet" device, append the "EtherNet/IP Slave Protocol" via the context menu.





- It's necessary to define a sync master for triggering EtherNet/IP Slave Protocol.
 - Option "Standard": the sync master has to be defined manually by the user. (f. e. PLC Task) (this option is not supported by CX9000series)
 - Option "Special Sync Task": a additional task will be created automatically

Important: The Sync Tasks Cycle Time represents the lowest border of the EtherNet/IP cycle time (RPI)


(e.g. task cycle time = 10ms ==> EtherNet/IP RPI_{min}=10ms)




5. Append an Ethernet/IP Slave Box as shown below



6. Append a Connection (Assembly) on the EtherNet/IP Slave Box as shown below



7. Depending on application requirements it's possible to define the size of Processdata Image separately for inputs and outputs from 1 up to 502 bytes. Please find an example for defining 8 Word Input Processdata as shown below.



Insert Variable

General

Name: Multiple:

Comment:

Start Address: Byte: Bit:

Variable Type

BIT8	1.0
BITARR8	1.0
BYTE	1.0
UINT16	2.0
INT16	2.0
UINT&ARR2	2.0
BITARR16	2.0
WORD	2.0
ENIUM	2.0

Sort by

Name


Size

Type

OK

Cancel

8. A valid EtherNet/IP Configuration is shown below



9. The Pre-Configuration of TwinCAT EtherNet/IP Slave is finished now. Activate the configuration and go on with Integration in RSLogix5000.

Integration in RSLogix5000

1. Open RSLogix 5000 and Create a new PLC project. When creating a new project make sure to select the correct controller type and controller settings. This example uses a CompactLogix (L32E) with the TwinCAT EtherNet/IP Slave

Example configured as shown above.

New Controller

Vendor: Allen-Bradley

Type: 1769-L32E CompactLogix5332E Controller

Revision: 15

Redundancy Enabled

Name: TEST

Description:



Chassis Type: <none>

Slot: 0 Safety Partner Slot:

Create In: c:\RSLogix 5000\Projects


OK
Cancel
Help
Browse...

2. Add a new module. When adding the TwinCAT EtherNet/IP Slave box, select the "ETHERNET-MODULE", since it is a generic Ethernet/IP device, and it will be configured to work with the TwinCAT EtherNet/IP Slave




3. Configuring the TwinCAT EtherNet/IP Slave in RSLogix:

- Enter IP-Address of TwinCAT EtherNet/IP Slave
- Choose Data Type (Comm Format)
- The Assembly Instances will be as follows:
 - Input(Target->Originator: 101
 - Output(Originator->Target: 102
 - Configuration: 100
- Things to keep in mind when entering the data size for I/O:
 - There will always be 4 bytes of input and 4 bytes of output data used for diagnostics.
 - The EtherNet/IP Slave Dialog View in TwinCAT Systemmanager (Subchapter "First Steps", Picture 8) assist you to find the correct data sizes.



1. Choose Requested Packet Interval in ms (shall not be lower than TwinCAT EtherNet/IP Slave Sync Task Cycle Time)
(Cycle Time in the TwinCAT Slave Example was set to 10ms)



3 Configuration TwinCAT 2.11 R3

The TwinCAT EtherNet/IP Slave enables EtherNet/IP Connectivity to the TwinCAT System.

Requirements:

- **Win2000 / Windows XP:** TwinCAT 2.11 R3
- If you use CE, the image must be also a TwinCAT 2.11 R3
- License Key for TwinCAT EtherNet/IP Slave Supplement product
- Intel PRO Network Interface Card (Ethernet Controller Intel 825X)

Installation

https://download.beckhoff.com/download/document/Application_Notes/DK9121-0111-0026.pdf

Download TwinCAT Supplement Installer for EtherNet/IP connectivity.

Operating System:

- Windows 2000 / XP/ Windows XP Embedded: [TS6280 | TwinCAT EthernetIP Slave](#)
- Windows CE: [TS6280-0030 | TwinCAT EthernetIP Slave CE](#)

Run the Installer on your programming PC and follow its instructions.

If the target operating system is Windows 2000 / Windows XP or Windows XP Embedded, the TwinCAT EtherNet/IP-Slave is now ready for Start-Up (go on with chapter "Start-Up").

If the target operating system is Windows CE, please follow the instructions below:

- The folder `..\TwinCAT\CE\TwinCAT EtherNetIP Slave CE\Install\ARM` contains a Cabinet-File (CAB file) for ARM-based CE runtime systems (e.g. CX9001, CX9010, CP66xx,...).
The folder `..\TwinCAT\CE\TwinCAT EtherNetIP Slave CE\Install\X86` contains a Cabinet-File for X86-based CE runtime systems (e.g. CX1000, CX1020, CP77xx, CP62xx, CP72xx, C69xx,...)
- Copy the file: `TcEtherNetIP_S_Ce.XXXXX.CAB` into a folder on the CE runtime system.
- On the CE system: Please install (double-click the CAB file) the CE components.
- **IMPORTANT:** Please suspend the CE device once after installation via "Start-> Suspend"!


Start-Up

General information


- At the moment, the TwinCAT EtherNet/IP Slave does only support static IP-Address configurations. When the TwinCAT EtherNet/IP Slave configuration is being activated, the System is only going to start up in RUN-Mode if the actual address settings match the stored configuration.

First Steps


1. Start the TwinCAT System Manager, create a new project and use the context menu after a mouse-click on "I/O Devices", to append a device in the I/O-Configuration




2. Choose "DeviceNet/Ethernet/IP" as shown below




3. Search the Ethernet Interface, if you don't find a interface you haven't install the RT-Ethernet driver!





4. Change to Sync Task, Create a new Task and change the Cycle Ticks to 10 ms.
Important: The Sync Tasks Cycle Time represents the lowest border of the EtherNet/IP cycle time (RPI)
 (e.g. task cycle time = 10ms ==> EtherNet/IP $RPI_{min}=10ms$)




5. It's necessary to define a sync master for triggering EtherNet/IP Slave Protocol.
 - Option "Standard": the sync master must be defined manually by the user. (f. e. PLC Task) (this option is not supported by CX9000series)
 - Option "Special Sync Task": a additional task will be created automatically




6. Append an EtherNet/IP Slave Box as shown below



7. Append a Connection (Assembly) on the EtherNet/IP Slave Box as shown below



8. Depending on application requirements it's possible to define the size of Processdata Image separately for inputs and outputs from 1 up to 502 bytes. Please find an example for defining 8 Word Input Processdata as shown below.



Insert Variable

General

Name: Multiple:

Comment:

Start Address: Byte: Bit:

Variable Type

BIT8	1.0
BITARR8	1.0
BYTE	1.0
UINT16	2.0
INT16	2.0
UINT8ARR2	2.0
BITARR16	2.0
WORD	2.0
...	...

Sort by

- Name
- Size
- Type

OK Cancel

9. A valid EtherNet/IP Configuration is shown below

The image shows a screenshot of the TwinCAT configuration interface. On the left is a tree view of I/O Devices. Under 'Device 1 (Ethernet I/P Slave)', there is a sub-entry 'Box 1 (TwinCAT EtherNet/IP Slave)' which contains an 'IO Assembly 1'. This assembly has 8 input variables (VAR_IN_!_1 to VAR_IN_!_8) and 16 output variables (VAR_OUT_1_1 to VAR_OUT_1_16). On the right is the 'Connection' dialog box. It has two tabs: 'General' and 'Connection'. The 'Connection' tab is active and shows configuration for 'Uplink (Target->Originator)' and 'Downlink (Originator->Target)'. The 'Uplink' section has 'Assembly Instance' set to 101, 'IP Address' set to 239.192.1.0, 'Port' set to 2222, and 'Size (in words)' set to 16 (+2). The 'Downlink' section has 'Assembly Instance' set to 102, 'IP Address' set to 0.0.0.0, 'Port' set to 2222, and 'Size (in words)' set to 8 (+2). The 'General - Parameter' section has 'SerialNo' set to 0 and 'Cycle Time (in ms)' set to 0. The 'Configuration - not used' section has 'Size (in words)' set to 0. Red circles highlight the 'Size (in words)' fields for both Uplink and Downlink.

10. The Pre-Configuration of TwinCAT EtherNet/IP Slave is finished now. Activate the configuration and go on with Integration in RSLogix5000.

Integration in RSLogix5000

1. Open RSLogix 5000 and Create a new PLC project. When creating a new project make sure to select the correct controller type and controller settings. This example uses a CompactLogix (L32E) with the TwinCAT EtherNet/IP Slave

Example configured as shown above.

New Controller

Vendor: Allen-Bradley

Type: 1769-L32E CompactLogix5332E Controller

Revision: 15

Redundancy Enabled

Name: TEST

Description:



Chassis Type: <none>

Slot: 0 Safety Partner Slot:

Create In: c:\RSLogix 5000\Projects


OK
Cancel
Help
Browse...

2. Add a new module. When adding the TwinCAT EtherNet/IP Slave box, select the "ETHERNET-MODULE", since it is a generic Ethernet/IP device, and it will be configured to work with the TwinCAT EtherNet/IP Slave




3. Configuring the TwinCAT EtherNet/IP Slave in RSLogix:

- Enter IP-Address of TwinCAT EtherNet/IP Slave
- Choose Data Type (Comm Format)
- The Assembly Instances will be as follows:
 - Input(Target->Originator: 101
 - Output(Originator->Target: 102
 - Configuration: 100
- Things to keep in mind when entering the data size for I/O:
 - There will always be 4 bytes of input and 4 bytes of output data used for diagnostics.
 - The EtherNet/IP Slave Dialog View in TwinCAT Systemmanager (Subchapter "First Steps", Picture 8) assist you to find the correct data sizes.



1. Choose Requested Packet Interval in ms (shall not be lower than TwinCAT EtherNet/IP Slave Sync Task Cycle Time)
(Cycle Time in the TwinCAT Slave Example was set to 10ms)



4 Error Codes

CN_ORC_ALREADY_USED 0x100 /* Connection already in use
CN_ORC_BAD_TRANSPORT 0x103 /* Transport type not supported
CN_ORC_OWNER_CONFLICT 0x106 /* More than one guy configuring
CN_ORC_BAD_CONNECTION 0x107 /* Trying to close inactive conn
CN_ORC_BAD_CONN_TYPE 0x108 /* Unsupported connection type
CN_ORC_BAD_CONN_SIZE 0x109 /* Connection size mismatch
CN_ORC_CONN_UNCONFIGURED 0x110 /* Connection unconfigured
CN_ORC_BAD_RPI 0x111 /* Unsupportable RPI
CN_ORC_NO_CM_RESOURCES 0x113 /* Conn Mgr out of connections
CN_ORC_BAD_VENDOR_PRODUCT 0x114 /* Mismatch in electronic key
CN_ORC_BAD_DEVICE_TYPE 0x115 /* Mismatch in electronic key
CN_ORC_BAD_REVISION 0x116 /* Mismatch in electronic key
CN_ORC_BAD_CONN_POINT 0x117 /* Nonexistant instance number
CN_ORC_BAD_CONFIGURATION 0x118 /* Bad config instance number
CN_ORC_CONN_REQ_FAILS 0x119 /* No controlling connection open
CN_ORC_NO_APP_RESOURCES 0x11A /* App out of connections

More Information:
www.beckhoff.de/ts6280

Beckhoff Automation GmbH & Co. KG
Hülshorstweg 20
33415 Verl
Germany
Phone: +49 5246 9630
info@beckhoff.com
www.beckhoff.com

