


Documentation | EN

## EJ3318

8-channel thermocouple input with open-circuit recognition





# Table of contents

<b>1</b>	<b>Foreword</b> .....	<b>5</b>
1.1	Notes on the documentation.....	5
1.2	Safety instructions .....	6
1.3	Intended use .....	7
1.4	Signal distribution board .....	7
1.5	Documentation issue status .....	7
1.6	Guide through documentation .....	8
1.7	Marking of EtherCAT plug-in modules.....	8
1.7.1	Beckhoff Identification Code (BIC).....	11
1.7.2	Electronic access to the BIC (eBIC) .....	13
1.7.3	Certificates.....	15
<b>2</b>	<b>System overview</b> .....	<b>16</b>
<b>3</b>	<b>EJ3318 - Product description</b> .....	<b>17</b>
3.1	Introduction .....	17
3.2	Technical data .....	18
3.3	Pinout .....	19
3.4	Notes for installation and commissioning .....	20
3.5	LEDs .....	23
<b>4</b>	<b>TC technology basics</b> .....	<b>24</b>
<b>5</b>	<b>Installation of EJ modules</b> .....	<b>26</b>
5.1	Power supply for the EtherCAT plug-in modules.....	26
5.2	EJxxxx - dimensions.....	28
5.3	Installation positions and minimum distances .....	29
5.3.1	Minimum distances for ensuring installability.....	29
5.3.2	Installation positions .....	30
5.4	Codings .....	32
5.4.1	Color coding.....	32
5.4.2	Mechanical position coding.....	33
5.5	Installation on the signal distribution board .....	34
5.6	Extension options .....	36
5.6.1	Using placeholder modules for unused slots .....	36
5.6.2	Linking with EtherCAT Terminals and EtherCAT Box modules via an Ethernet/EtherCAT connection .....	37
5.7	IPC integration .....	38
5.8	Disassembly of the signal distribution board .....	40
5.9	Disposal .....	40
<b>6</b>	<b>EtherCAT basics</b> .....	<b>41</b>
<b>7</b>	<b>Commissioning</b> .....	<b>42</b>
7.1	Note on documentation for the EL33xx .....	42
<b>8</b>	<b>EJ3318 - Object description and parameterization</b> .....	<b>43</b>
8.1	Restore object .....	44
8.2	Configuration data .....	44
8.3	Profile-specific objects (0x6000-0xFFFF).....	45

---

8.4	Input data.....	46
8.5	Output data.....	46
8.6	Configuration data vendor specific .....	47
8.7	Information and diagnostic data .....	47
8.8	Standard objects (0x1000-0x1FFF).....	48
<b>9</b>	<b>Appendix .....</b>	<b>54</b>
9.1	Support and Service .....	54

# 1 Foreword

## 1.1 Notes on the documentation

### Intended audience

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning these components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

### Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

### Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH. Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

### Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents: EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702 with corresponding applications or registrations in various other countries.

The logo for EtherCAT, featuring the word "EtherCAT" in a bold, black, sans-serif font. A red arrow points from the top of the "A" towards the right, ending above the "T". A registered trademark symbol (®) is located to the right of the "T".

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

### Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

## 1.2 Safety instructions

### Safety regulations

Please note the following safety instructions and explanations!  
Product-specific safety instructions can be found on following pages or in the areas mounting, wiring, commissioning etc.

### Exclusion of liability

All the components are supplied in particular hardware and software configurations appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

### Personnel qualification

This description is only intended for trained specialists in control, automation and drive engineering who are familiar with the applicable national standards.

### Description of instructions

In this documentation the following instructions are used.  
These instructions must be read carefully and followed without fail!

#### **DANGER**

##### **Serious risk of injury!**

Failure to follow this safety instruction directly endangers the life and health of persons.

#### **WARNING**

##### **Risk of injury!**

Failure to follow this safety instruction endangers the life and health of persons.

#### **CAUTION**

##### **Personal injuries!**

Failure to follow this safety instruction can lead to injuries to persons.

#### **NOTE**

##### **Damage to environment/equipment or data loss**

Failure to follow this instruction can lead to environmental damage, equipment damage or data loss.



##### **Tip or pointer**

This symbol indicates information that contributes to better understanding.

## 1.3 Intended use

### ⚠ WARNING

#### Caution - Risk of injury!

EJ components may only be used for the purposes described below!

## 1.4 Signal distribution board

### NOTE

#### Signal distribution board

Make sure that the EtherCAT plug-in modules are used only on a signal distribution board that has been developed and manufactured in accordance with the [Design Guide](#).

## 1.5 Documentation issue status

Version	Modifications
2.2	<ul style="list-style-type: none"> <li>• Update chapter <i>Marking of EtherCAT plug-in modules</i></li> <li>• Update Technical Data</li> <li>• Chapter <i>Disposal</i> added</li> <li>• Update structure</li> </ul>
2.1	<ul style="list-style-type: none"> <li>• Title page new</li> <li>• Chapter <i>Version identification of EtherCAT devices</i> replaced by chapter <i>Marking of EtherCAT plug-in modules</i></li> <li>• Update chapter <i>Technical data</i></li> <li>• Update chapter <i>Pinout</i></li> <li>• Chapter <i>TC technology basics</i> added</li> <li>• Update chapter <i>EJ3318 - Notes for commissioning</i></li> <li>• Note <i>Signal distribution board</i> added</li> <li>• Chapter <i>Basics communication, TwinCAT Quickstart and TwinCAT Development Environment, General - EtherCAT Slave Application</i> replaced by links in chapter <i>Guide through documentation</i></li> <li>• Chapter <i>EJ3318 - Object description and parameterization</i> added</li> <li>• Structural update</li> <li>• Update revision status</li> </ul>
2.0	<ul style="list-style-type: none"> <li>• 1<sup>st</sup> publication EJ3318</li> <li>• Chapter <i>Intended use</i> added</li> <li>• Chapter <i>System overview</i> added</li> <li>• Chapter <i>Product overview</i> updated</li> <li>• Chapter <i>Basics communication</i> added</li> <li>• Chapter <i>Mounting and wiring</i> replaced by chapter <i>Installation of EJ modules</i></li> <li>• Update Chapter <i>Appendix</i></li> </ul>
1.0	<ul style="list-style-type: none"> <li>• First version</li> </ul>

## 1.6 Guide through documentation

### NOTE



#### Further components of documentation

The documentations named in the following table are further components of the complete documentation. These documentations are required for the use of EtherCAT plug-in modules.

No.	Title	Description
[1]	<u>EtherCAT System Documentation</u>	<ul style="list-style-type: none"> <li>• System overview</li> <li>• EtherCAT basics</li> <li>• Cable redundancy</li> <li>• Hot Connect</li> <li>• Distributed Clocks</li> <li>• Configuration of EtherCAT-Components</li> </ul>
[2]	<u>Infrastructure for EtherCAT/Ethernet</u>	<ul style="list-style-type: none"> <li>• Technical recommendations and notes for design, implementation an testing</li> </ul>
[3]	<u>Design GuideSignal-Distribution-Board for standard EtherCAT plug-in modules</u>	Requirements for the design of a Signal-Distribution-Board for standard EtherCAT plug-in modules <ul style="list-style-type: none"> <li>• Backplane mounting guidelines</li> <li>• Module placement</li> <li>• Routing guidelines</li> </ul>
[4]	Documentation of the corresponding terminal ELxxxx	<ul style="list-style-type: none"> <li>• Notes on the principle of operation and</li> <li>• Descriptions for configuration and parameterization</li> </ul> are transferable to the corresponding Module EJxxxx (s. <u>note on documentation of ELxxxx</u> [▶ 42]).

## 1.7 Marking of EtherCAT plug-in modules

### Designation

A Beckhoff EtherCAT device has a 14-digit **technical designation**, made up as follows (e.g. EJ1008-0000-0017)

- **Order identifier**
  - family key: EJ
  - product designation: The first digit of product designation is used for assignment to a product group (e.g. EJ2xxx = digital output module).
  - Version number: The four digit version number identifies different product variants.
- **Revision number:**  
It is incremented when changes are made to the product.

The Order identifier and the revision number are printed on the side of EtherCAT plug-in modules (s. following illustration (A and B).






Fig. 1: Order identifier (A), Revision number (B) and serial number (C) using the example of EJ1008

Product group	Example		
	Product designation	Version	Revision
EtherCAT Coupler EJ11xx	EJ1101	-0022 (Coupler with external connectors, power supply module and optional ID switches)	-0016
Digital input modules EJ1xxx	EJ1008 8-channel	-0000 (basic type)	-0017
Digital output modules EJ2xxx	EJ2521 1-channel	-0224 (2 x 24 V outputs)	-0016
Analog input modules EJ3xxx	EJ3318 8-channel thermocouple	-0000 (basic type)	-0017
Analog output modules EJ4xxx	EJ4134 4-channel	-0000 (basic type)	-0019
Special function modules EJ5xxx, EJ6xxx	EJ6224 IO-Link master	-0090 (with TwinSAFE SC)	-0016
Motion modules EJ7xxx	EJ7211 servomotor	-9414 (with ECT, STO and TwinSAFE SC)	-0029

**Notes**

- The elements mentioned above result in the **technical designation**. EJ1008-0000-0017 is used in the example below.
- EJ1008-0000 is the **order identifier**, in the case of “-0000” usually abbreviated to EJ1008.
- The **revision** -0017 shows the technical progress, such as the extension of features with regard to the EtherCAT communication, and is managed by Beckhoff.  
In principle, a device with a higher revision can replace a device with a lower revision, unless specified otherwise, e.g. in the documentation.  
Associated and synonymous with each revision there is usually a description (ESI, EtherCAT Slave Information) in the form of an XML file, which is available for [download](#) from the Beckhoff web site.
- The product designation, version and revision are read as decimal numbers, even if they are technically saved in hexadecimal.

**Serial number**

The serial number for EtherCAT plug-in modules is usually the 8-digit number printed on the side of the module (see following illustration C). The serial number indicates the configuration in delivery state and therefore refers to a whole production batch, without distinguishing the individual modules of a batch.




Fig. 2: Order identifier (A), revision number (B) and serial number (C) using the example of EJ1008

Serial number	Example serial number: 08 15 08 16
KK - week of production (CW, calendar week)	08 - week of production: 08
YY - year of production	15 - year of production: 2015
FF - firmware version	08 - firmware version: 08
HH - hardware version	16 - hardware version: 16

## 1.7.1 Beckhoff Identification Code (BIC)

The Beckhoff Identification Code (BIC) is increasingly being applied to Beckhoff products to uniquely identify the product. The BIC is represented as a Data Matrix Code (DMC, code scheme ECC200), the content is based on the ANSI standard MH10.8.2-2016.




Fig. 3: BIC as data matrix code (DMC, code scheme ECC200)

The BIC will be introduced step by step across all product groups.

Depending on the product, it can be found in the following places:

- on the packaging unit
- directly on the product (if space suffices)
- on the packaging unit and the product

The BIC is machine-readable and contains information that can also be used by the customer for handling and product management.

Each piece of information can be uniquely identified using the so-called data identifier (ANSI MH10.8.2-2016). The data identifier is followed by a character string. Both together have a maximum length according to the table below. If the information is shorter, it shall be replaced by spaces. The data under positions 1-4 are always available.

The following information is contained:

Item no.	Type of information	Explanation	Data identifier	Number of digits incl. data identifier	Example
1	Beckhoff order number	<b>Beckhoff order number</b>	1P	8	<b>1</b> P072222
2	Beckhoff Traceability Number (BTN)	<b>Unique serial number, see note below</b>	S	12	<b>S</b> BTNk4p562d7
3	Article description	<b>Beckhoff article description, e.g. EL1008</b>	1K	32	<b>1</b> KEL1809
4	Quantity	<b>Quantity in packaging unit, e.g. 1, 10, etc.</b>	Q	6	<b>Q</b> 1
5	Batch number	Optional: Year and week of production	2P	14	<b>2</b> P401503180016
6	ID/serial number	Optional: Present-day serial number system, e.g. with safety products	51S	12	<b>51</b> S678294104
7	Variant number	Optional: Product variant number on the basis of standard products	30P	32	<b>30</b> PF971 , 2*K183
...					

Further types of information and data identifiers are used by Beckhoff and serve internal processes.

### Structure of the BIC

Example of composite information from items 1 - 4 and with the above given example value on position 6. The data identifiers are marked in bold font for better display:

**1**P072222**S**BTNk4p562d7**1**KEL1809 **Q**1 **51**S678294

Accordingly as DMC:



Fig. 4: Example DMC **1**P072222**S**BTNk4p562d7**1**KEL1809 **Q**1 **51**S678294

### BTN

An important component of the BIC is the Beckhoff Traceability Number (BTN, item no. 2). The BTN is a unique serial number consisting of eight characters that will replace all other serial number systems at Beckhoff in the long term (e.g. batch designations on IO components, previous serial number range for safety products, etc.). The BTN will also be introduced step by step, so it may happen that the BTN is not yet coded in the BIC

### NOTE

This information has been carefully prepared. However, the procedure described is constantly being further developed. We reserve the right to revise and change procedures and documentation at any time and without prior notice. No claims for changes can be made from the information, illustrations and descriptions in this information.

## 1.7.2 Electronic access to the BIC (eBIC)

### Electronic BIC (eBIC)

The Beckhoff Identification Code (BIC) is applied to the outside of Beckhoff products in a visible place. If possible, it should also be electronically readable.

Decisive for the electronic readout is the interface via which the product can be electronically addressed.

### K-bus devices (IP20, IP67)

Currently, no electronic storage and readout is planned for these devices.


### EtherCAT devices (IP20, IP67)

All Beckhoff EtherCAT devices have a so-called ESI-EEPROM, which contains the EtherCAT identity with the revision number. Stored in it is the EtherCAT slave information, also colloquially known as ESI/XML configuration file for the EtherCAT master. See the corresponding chapter in the EtherCAT system manual ([Link](#)) for the relationships.

The eBIC is also stored in the ESI-EEPROM. The eBIC was introduced into the Beckhoff I/O production (terminals, boxes) from 2020; widespread implementation is expected in 2021.

The user can electronically access the eBIC (if existent) as follows:

- With all EtherCAT devices, the EtherCAT master (TwinCAT) can read the eBIC from the ESI-EEPROM
  - From TwinCAT 4024.11, the eBIC can be displayed in the online view.
  - To do this, check the checkbox "Show Beckhoff Identification Code (BIC)" under EtherCAT → Advanced Settings → Diagnostics:



- The BTN and its contents are then displayed:

No	Addr	Name	State	CRC	Fw	Hw	Production Data	ItemNo	BTN	Description	Quantity	BatchNo	SerialNo
1	1001	Term 1 (EK1100)	OP	0,0	0	0	---						
2	1002	Term 2 (EL1018)	OP	0,0	0	0	2020 KW36 Fr	072222	k4p562d7	EL1809	1		678294
3	1003	Term 3 (EL3204)	OP	0,0	7	6	2012 KW24 Sa						
4	1004	Term 4 (EL2004)	OP	0,0	0	0	---	072223	k4p562d7	EL2004	1		678295
5	1005	Term 5 (EL1008)	OP	0,0	0	0	---						
6	1006	Term 6 (EL2008)	OP	0,0	0	12	2014 KW14 Mo						
7	1007	Term 7 (EK1110)	OP	0	1	8	2012 KW25 Mo						

- Note: as can be seen in the illustration, the production data HW version, FW version and production date, which have been programmed since 2012, can also be displayed with "Show Production Info".
- In the case of EtherCAT devices with CoE directory, the object 0x10E2:01 can additionally be used to display the device's own eBIC; the PLC can also simply access the information here:

- The device must be in SAFEOP/OP for access:

Index	Name	Flags	Value
1000	Device type	RO	0x015E1389 (22942601)
1008	Device name	RO	ELM3704-0000
1009	Hardware version	RO	00
100A	Software version	RO	01
100B	Bootloader version	RO	J0.1.27.0
1011:0	Restore default parameters	RO	> 1 <
1018:0	Identity	RO	> 4 <
10E2:0	Manufacturer-specific Identification C...	RO	> 1 <
10E2:01	SubIndex 001	RO	1P158442SBTN0008jexp1KELM3704 Q1 2P482001000016
10F0:0	Backup parameter handling	RO	> 1 <
10F3:0	Diagnosis History	RO	> 21 <
10F8	Actual Time Stamp	RO	0x170bf277e

- the object 0x10E2 will be introduced into stock products in the course of a necessary firmware revision.
- Note: in the case of electronic further processing, the BTN is to be handled as a string(8); the identifier "SBTN" is not part of the BTN.
- Technical background  
The new BIC information is additionally written as a category in the ESI-EEPROM during the device production. The structure of the ESI content is largely dictated by the ETG specifications, therefore the additional vendor-specific content is stored with the help of a category according to ETG.2010. ID 03 indicates to all EtherCAT masters that they must not overwrite these data in case of an update or restore the data after an ESI update.  
The structure follows the content of the BIC, see there. This results in a memory requirement of approx. 50..200 bytes in the EEPROM.
- Special cases
  - If multiple, hierarchically arranged ESCs are installed in a device, only the top-level ESC carries the eBIC Information.
  - If multiple, non-hierarchically arranged ESCs are installed in a device, all ESCs carry the eBIC Information.
  - If the device consists of several sub-devices with their own identity, but only the top-level device is accessible via EtherCAT, the eBIC of the top-level device is located in the CoE object directory 0x10E2:01 and the eBICs of the sub-devices follow in 0x10E2:nn.

### Profibus/Profinet/DeviceNet... Devices

Currently, no electronic storage and readout is planned for these devices.

### 1.7.3 Certificates

- The EtherCAT plug-in modules meet the requirements of the EMC and Low Voltage Directive. The CE mark is printed on the side of the modules.
- The cRUus imprint identifies devices that meet product safety requirements according to U.S. and Canadian regulations.
- The warning symbol is a request to read the corresponding documentation. The documentations for EtherCAT plug-in modules can be downloaded from the Beckhoff [homepage](#).



Fig. 5: Marking for CE and UL using EJ1008 as an example

## 2 System overview

Electronically, the EJxxxx EtherCAT plug-in modules are based on the EtherCAT I/O system. The EJ system consists of the signal distribution board and EtherCAT plug-in modules. It is also possible to connect an IPC to the EJ system.

The EJ system is suitable for mass production applications, applications with small footprint and applications requiring a low total weight.

The machine complexity can be extended by means of the following:

- reserve slots,
- the use of placeholder modules,
- linking of EtherCAT Terminals and EtherCAT Boxes via an EtherCAT connection.

The following diagram illustrates an EJ system. The components shown are schematic, to illustrate the functionality.




Fig. 6: EJ system sample

### Signal distribution board

The signal distribution board distributes the signals and the power supply to individual application-specific plug connectors, in order to connect the controller to further machine modules. Using pre-assembled cable harnesses avoids the need for time-consuming connection of individual wires. Coded components reduce the unit costs and the risk of miswiring.

Beckhoff offers development of signal distribution boards as an engineering service. Customers have the option to develop their own signal distribution board, based on the design guide.

### EtherCAT plug-in modules

Similar to the EtherCAT terminal system, a module strand consists of a Bus Coupler and I/O modules. Almost all of the EtherCAT Terminals can also be manufactured in the EJ design as EtherCAT plug-in modules. The EJ modules are directly attached to the signal distribution board. The communication, signal distribution and supply take place via the contact pins at the rear of the modules and the PCB tracks of the signal distribution board. The coding pins at the rear serve as mechanical protection against incorrect connection. Color coding on the housing facilitates distinguishing of the modules.



## 3 EJ3318 - Product description

### 3.1 Introduction




Fig. 7: EJ3318

#### **8-channel input, thermocouple with open-circuit recognition**

The EJ3318 EtherCAT module enables the direct connection of eight thermocouples. The circuit of the EtherCAT module can operate thermocouple sensors in 2-wire technology. A microprocessor handles linearization across the whole temperature range, which is freely selectable. Cold junction compensation is achieved by external temperature measurement via RTDs. Measurements in the mV range are also possible with the EJ3318 EtherCAT plug-in module.

The error LEDs indicate a broken wire.

## 3.2 Technical data

Technical data	EJ3318
Number of inputs	8 x TC 2 x PT1000 for cold junction compensation
Power supply	via the E-bus
Thermocouple sensor types	types J, K, L, B, E, N, R, S, T, U (default setting type K), mV measurement
Distributed Clocks	-
Maximum cable length to the sensor	30 m (see note [▶ 18])
Input filter limit frequency	typ. 1 kHz; depending on sensor length, conversion time, sensor type
Connection technology	2-wire
Open-circuit recognition	yes
Conversion time	approx. 5 s up to 40 ms, depending on configuration and filter setting, preset approx. 500 ms
Temperature range	defined in the range for each sensor (preset: type K; -200..+1370 °C); voltage measurement ±30 mV..±75 mV
Resolution	0.1 °C/ digit
Measuring error	< ±0.3 % (relative to full scale value FSV)
Open-circuit recognition	yes
Electrical isolation	500 V (E-bus/signal voltage)
Current consumption load voltage (Up contacts)	-
Current consumption via E-bus	190 mA
Special features	Idle detection, error detection of external cold junction compensation (CJC)
Permissible ambient temperature range during operation	-25 °C .. + 60 °C (extended temperature range)
Permissible ambient temperature range during storage	-40°C .. +85°C
Permissible relative air humidity	95 %, no condensation
Operating altitude	max.2,000 m
Dimensions (W x H x D)	approx. 12 mm x 66 mm x 55 mm
Pollution degree	2
Weight	approx. 30 g
Mounting	on signal distribution board
Mounting position	Standard [▶ 30]
Position of the coding pins [▶ 33]	2 and 7
Color coding	green
Vibration / shock resistance	conforms to EN60068-2-6 / EN 60068-2-27 (with corresponding signal distribution board)
EMC immunity / emission	conforms to EN 61000-6-2 /EN 61000-6-4 (with corresponding signal distribution board)
Protection class	EJ module: IP20 EJ system: dependent on the signal distribution board and housing
Approvals / markings	CE, EAC, UKCA, UL

### **i** CE approval

The CE Marking refers to the EtherCAT plug-in module mentioned above. If the EtherCAT plug-in module is used in the production of a ready-to-use end product (PCB in conjunction with a housing), the manufacturer of the end product must check compliance of the overall system with relevant directives and CE certification. To operate the EtherCAT plug-in modules, they must be installed in a housing.

### **i** Maximum cable length to the sensor

Without additional protective measures, the maximum cable length from the EtherCAT Module to the sensor is 30 m. For longer cable lengths, suitable surge protection should be provided.

### 3.3 Pinout

EJ3318			
Pin#		Signal	
1	2	$U_{EBUS}$	$U_{EBUS}$
3	4	GND	GND
5	6	RX0+	TX1+
7	8	RX0-	TX1-
9	10	GND	GND
11	12	TX0+	RX1+
13	14	TX0-	RX1-
15	16	GND	GND
17	18	TC1-	TC1+
19	20	TC2-	TC2+
21	22	TC3-	TC3+
23	24	TC4-	TC4+
25	26	TC5-	TC5+
27	28	TC6-	TC6+
29	30	TC7-	TC7+
31	32	TC8-	TC8+
33	34	R1- PT1000	R1+ PT1000
35	36	R2- PT1000	R2+ PT1000
37	38	NC	NC
39	40	SGND	SGND

**E-Bus contacts**

The power supply  $U_{EBUS}$  is provided by the coupler and supplied from the supply voltage  $U_S$  of the EtherCAT coupler.

**Signals**

**$U_P$ -Contacts**


The device has no  $U_P$ -contacts. The power is supplied exclusively via  $U_{EBUS}$ .

Signal	Description
$U_{EBUS}$	E-Bus power supply 3.3 V
GND	E-Bus GND signal. Don't connect with 0V $U_P$ !
RXn+	Positive E-Bus receive signal
RXn-	Negative E-Bus receive signal
TXn+	Positive E-Bus transmit signal
TXn-	Negative E-Bus transmit signal
TC1-...TC8-	Inputs TC1-...TC8-
TC1+...TC8+	Inputs TC1+...TC8+
R1- PT1000	Input R1-
R2- PT1000	Input R2-
R1+ PT1000	Input R1+
R2+ PT1000	Input R2+
NC	Do not connect
SGND	Shield Ground

Fig. 8: EJ3318 - Pinout

The PCB footprint can be downloaded from the Beckhoff [homepage](#).

NOTE



**Damage to devices possible!**

- The pins named with "NC" must not be connected.
- Before installation and commissioning read the chapters [Installation of EJ modules](#) [▶ 26] and [Commissioning](#) [▶ 42]!

### 3.4 Notes for installation and commissioning



The accuracy of the TC-temperature-measurement is directly affected by the cold-junction-measurement. So some design guidelines have to be followed!

- Use high quality PT1000 with low tolerance, put the PT1000 very close to the TC-connector on the backplane or wherever the cold-junction is located.
- Avoid parasitic resistances in the RTD-circuit e.g. bad connection or long leads, +3 Ohms → +1°C.
- Put ground-shield around the traces to avoid emi-disturbances.
- Avoid excessive external heating (e.g. near transformer) or cooling (e.g. air flow) of the PT1000 sensor so that its temperature becomes significantly different from the connector of the TC-elements.
- Wire-calibration can be done with indexes 0x8080:1B and 0x8090:1B.

#### Notes for measurement of cold-junction-temperature

Measurement and calculation of the correct temperature with TC-elements require also to measure the so called cold-junction-temperature. The cold-junction-temperature is measured by two RTDs. They should be connected very close to the connection of TCs onto the backplane (change from TC-material to copper).




Fig. 9: TC/ RTD connectors on the backplane

#### Examples:

1. One isothermal block → all TC-connections on the backplane are located closely at one place and have the same temperature:
  - one RTD is sufficient, any TC can be referenced to e.g. “RTD1”




Fig. 10: One isothermal block

2. Two isothermal blocks with different temperatures and each with an own RTD:
  - the number of TCs on the one and the other block can be freely selected, e.g. TCs 1-3-4-7-8 close to RTD1 and TCs 2-5-6 close to RTD2.
3. If there is a temperature gradient along the connecting terminals of the TCs,
  - an average temperature of RTD1 and RTD2 could be calculated by a PLC and provided as process data.
  - In this case the TC-channels 1 .. 4 should be referenced to CJ1, the TC-channels 5 .. 8 should be referenced to CJ2.




Fig. 11: Temperature gradient along the connecting terminals of the TCs

4. If necessary the TC-channels can be routed to two different TC-connectors. Follow the rules mentioned above!



Fig. 12: TC-channels routed to two different TC-connectors

**Settings of coldjunction compensation**

Preset for each channel is *intern RTD Ch1*, the assignment can be chosen separately for each channel in index 0x80n0:0C (n=0: Channel 1 .. n=7: Channel 8).

8000:0	TC Settings Ch.1	RW	> 25 <
8000:01	Enable user scale	RW	FALSE
8000:02	Presentation	RW	signed (0)
8000:05	Siemens bits	RW	FALSE
8000:06	Enable filter	RW	FALSE
8000:0A	Enable user calibration	RW	FALSE
8000:0B	Enable vendor calibration	RW	TRUE
8000:0C	Coldjunction compensation	RW	intern RTD Ch1 (0)
8000:11	User scale offset	RW	0
8000:12	User scale gain	RW	65536
8000:15	Filter settings	RW	50 Hz (0)
8000:17	User calibration offset	RW	0
8000:18	user calibration gain	RW	0xFFFF (65535)
8000:19	TC Element	RW	K -200...1370°C (0)

Fig. 13: TC Settings taking Ch.1 as an example, Index 0x8000:0C




Fig. 14: CJC selection dialog

Name	Value	Description
intern RTD Ch1	0 <sub>dec</sub>	The coldjunction compensation takes place via <i>intern RTD Ch1</i> of the module (default).
no	1 <sub>dec</sub>	The coldjunction compensation is not active
extern procesdata (1/10°C)	2 <sub>dec</sub>	The coldjunction compensation takes place via the process data 0x160n (n=0: Channel 1 .. n=7: Channel 8). These must then be mapped via the PDO assignment.
intern RTD Ch2	3 <sub>dec</sub>	The coldjunction compensation takes place via <i>intern RTD Ch2</i> of the module.

**Other settings:**

1. Filter: the index 0x8000:15 is valid for all channels, default 50 Hz
2. Index 0x80x0:18 - TC element setting for each channel separately

### 3.5 LEDs

LED No.	EJ3318
A	RUN
B	
C	
1	ERR 1
2	ERR 2
3	ERR 3
4	ERR 4
5	ERR 5
6	ERR 6
7	ERR 7
8	ERR 8
9	ERR 9
10	ERR 10
11	
12	
13	
14	
15	
16	

Fig. 15: EJ3318 - LEDs

LED	Color	Description	
RUN	green	off	State of the EtherCAT State Machine: <b>INIT</b> = initialization of the module
		flashing	State of the EtherCAT State Machine: <b>PREOP</b> = function for mailbox communication and different default settings set
		single flash	State of the EtherCAT State Machine: <b>SAFEOP</b> = Check the channels of the Sync Manager and the Distributed Clocks (if supported)
		on	State of the EtherCAT State Machine: <b>OP</b> = normal operating state; mailbox and process data communication is possible
		flickering	State of the EtherCAT State Machine: <b>BOOTSTRAP</b> = Function for firmware updates of the module

LED	Color	Display	State	Description
ERR 1 .. 8	red	off	-	No error
		on	-	Error TC 1 .. 8
ERR 9	red	off	-	No error
		on	-	Error 9 CJC PT1000
ERR 10	red	off	-	No error
		on	-	Error 10 CJC PT1000

## 4 TC technology basics

The thermocouple modules can evaluate thermocouples of the types B, C, E, J, K, L, N, R, S, T and U. The characteristic curves are linearized and the reference temperature determined directly within the module. Temperatures are output in  $1/10^{\circ}\text{C}$ , for example (device-dependent). The module is fully configurable via the bus coupler or the control system. Different output formats may be selected or own scaling activated. In addition, linearization of the characteristic curve and determination and calculation of the reference temperature (temperature at the terminal connection contacts) can be switched off.

### Measuring principle of the thermocouple

Thermocouples can be classified as active transducers. They exploit the thermo-electric effect (Seebeck, Peltier, Thomson). A voltage referred to as thermovoltage occurs over the length of a cable with different temperatures at both ends. It is an unambiguous function of the temperature and the material. In a "TC element" this effect is utilized by operating two different conductor materials in parallel (s. fig. [▶ 24].)




Fig. 16: Principle of the thermocouple

Example:

In the following example, the voltage  $U_{th}$  is given which is present at a type-K thermocouple at the temperature  $T_m$ .

$$U_{th} = (k_{NiCr} - k_{Ni}) \times \Delta T$$

with

$$\Delta T = T_m - T_v$$



A type-K thermocouple consists of a junction of a nickel-chrome alloy and nickel, where  $k_{NiCr}$  and  $k_{Ni}$  represent the thermoelectric coefficients of nickel-chrome and nickel respectively. By adapting the equation according to  $T_m$ , the sought-after temperature can be calculated from the voltage measured across the thermocouple. Based on the difference to the cold junction temperature, the temperature at the measurement point can be determined to an accuracy of better than one tenth of a Kelvin with the aid of the above thermocouple equation.

● **Sensor circuit**

**i** A modification of the sensor circuit with additional devices such as change over switches or multiplexer decreases the measure accuracy. We strongly advise against such modifications.

**Internal conversion of the thermovoltage and the reference voltage**

Since the coefficients are determined at a reference temperature of 0°C, it is necessary to compensate for the effect of the reference temperature. This is done by converting the reference temperature into a reference voltage that depends on the type of thermocouple, and adding this to the measured thermovoltage. The temperature is found from the resulting voltage and the corresponding characteristic curve.

$$U_k = U_m + U_r$$

$$T_{out} = f(U_k)$$

**Overview of suitable thermocouples**

The following thermocouples are suitable for temperature measurement:

Type (according to EN60584-1)	Element	Implemented temperature range	Color coding (sheath - plus pole - minus pole)
B	Pt30%Rh-Pt6Rh	600°C to 1800°C	grey - grey - white
C *	W5%Re-W25%Re	0°C to 2320°C	n.d.
E	NiCr-CuNi	-100°C to 1000°C	violet - violet - white
J	Fe-CuNi	-100°C to 1200°C	black - black - white
K	NiCr-Ni	-200°C to 1370°C	green - green - white
L **	Fe-CuNi	0°C to 900°C	blue - red - blue
N	NiCrSi-NiSi	-100°C to 1300°C	pink - pink - white
R	Pt13%Rh-Pt	0°C to 1767°C	orange - orange - white
S	Pt10%Rh-Pt	0°C to 1760°C	orange - orange - white
T	Cu-CuNi	-200°C to 400°C	brown - brown - white
U **	Cu-CuNi	0°C to 600°C	brown - red - brown

\* not standardized according to EN60584-1

\*\* according to DIN 43710

● **Maximum cable length to the sensor**

**i** Without additional protective measures, the maximum cable length from the EtherCAT Module to the sensor is 30 m. For longer cable lengths, suitable surge protection should be provided.

## 5 Installation of EJ modules

### 5.1 Power supply for the EtherCAT plug-in modules

**⚠ WARNING**

**Power supply**

A SELV/PELV power supply must be used to supply power for the EJ coupler and modules. Couplers and modules have to be connected to SELV/PELV circuits exclusively.

The signal distribution board should have a power supply designed for the maximum possible current load of the module string. Information on the current required from the E-bus supply can be found for each module in the respective documentation in section “Technical data”, online and in the catalog. The power requirement of the module string is displayed in the TwinCAT System Manager.

**E-bus power supply with EJ1100 or EJ1101-0022 and EJ940x**

The EJ1100 Bus Coupler supplies the connected EJ modules with the E-bus system voltage of 3.3 V. The Coupler can accommodate a load up to 2.2 A. If a higher current is required, a combination of the coupler EJ1101-0022 and the power supply units EJ9400 (2.5 A) or EJ9404 (12 A) should be used. The EJ940x power supply units can be used as additional supply modules in the module string.

Depending on the application, the following combinations for the E-bus supply are available:

Coupler EJ1100 with integrated power supply unit (2.2 A)

coupler EJ1101-0022 + ext. RJ45 and optional ID switches + power supply unit EJ9400 (2.5 A)

coupler EJ1101-0022 + ext. RJ45 and optional ID switches + power supply unit EJ9404 (12 A)




Fig. 17: E-bus power supply with EJ1100 or EJ1101-0022 + EJ940x

In the EJ1101-0022 coupler, the RJ45 connectors and optional ID switches are external and can be positioned anywhere on the signal distribution board, as required. This facilitates feeding through a housing.

The EJ940x power supply plug-in modules provide an optional reset function (see chapter Connection of the documentation for EJ9400 and EJ9404)

**E-bus power supply with CXxxxx and EK1110-004x**

The Embedded PC supplies the attached EtherCAT terminals and the EtherCAT EJ coupler

- with a supply voltage  $U_s$  of 24 V<sub>DC</sub> (-15 %/+20%). This voltage supplies the E-bus and the bus terminal electronics.  
The CXxxxx units supply the E-bus with up to 2,000 mA E-bus current. If a higher current is required due to the attached terminals, power feed terminals or power supply plug-in modules must be used for the E-bus supply.
- with a peripheral voltage  $U_p$  of 24 V<sub>DC</sub> to supply the field electronics.

The EK1110-004x EtherCAT EJ couplers relay the following parameters to the signal distribution board via the rear connector:

- the E-bus signals,
- the E-bus voltage  $U_{EBUS}$  (3.3 V) and
- the peripheral voltage  $U_p$  (24 V<sub>DC</sub>).



Fig. 18: PCB with Embedded PC, EK1110-0043 and EJxxxx, rear view EK1110-0043

## 5.2 EJxxxx - dimensions

The EJ modules are compact and lightweight thanks to their design. Their volume is approx. 50% smaller than the volume of the EL terminals. A distinction is made between four different module types, depending on the width and the height:

Module type	Dimensions (W x H x D)	Sample in figure below
Coupler	44 mm x 66 mm x 55 mm	EJ1100 (ej_44_2xrxj45_coupler)
Single module	12 mm x 66 mm x 55 mm	EJ1809 (ej_12_16pin_code13)
Double module	24 mm x 66 mm x 55 mm	EJ7342 (ej_24_2x16pin_code18)
Single module (long)	12 mm x 152 mm x 55 mm	EJ1957 (ej_12_2x16pin_extended_code4747)




Fig. 19: EJxxxx - Dimensions

The technical drawings can be downloaded from the Beckhoff [homepage](#). The drawings are named as described in the drawing below.




Fig. 20: Naming of the technical drawings

## 5.3 Installation positions and minimum distances

### 5.3.1 Minimum distances for ensuring installability

Note the dimensions shown in the following diagram for the design of the signal distribution board to ensure safe latching and simple assembly / disassembly of the modules.




Fig. 21: Mounting distances EJ module - PCB

#### **i** Observing the reaching area

A minimum reaching area of 92 mm is required for assembly / disassembly, in order to be able to reach the mounting tabs with the fingers.

Adherence to the recommended minimum distances for ventilation (see [section Installation position \[▶ 30\]](#)) ensures an adequate reaching area.

The signal distribution board must have a thickness of 1.6 mm and a minimum distance of 4 mm from the mounting surface, in order to ensure latching of the modules on the board.

### 5.3.2 Installation positions

#### NOTE

##### Constraints regarding installation position and operating temperature range

Please refer to the [technical data](#) [▶ 18] for the installed components to ascertain whether any restrictions regarding the mounting position and/or the operating temperature range have been specified. During installation of modules with increased thermal dissipation, ensure adequate distance above and below the modules to other components in order to ensure adequate ventilation of the modules during operation!

The standard installation position is recommended. If a different installation position is used, check whether additional ventilation measures are required.

Ensure that the specified conditions (see Technical data) are adhered to!

##### Optimum installation position (standard)

For the optimum installation position the signal distribution board is installed horizontally, and the fronts of the EJ modules face forward (see Fig. *Recommended distances for standard installation position*). The modules are ventilated from below, which enables optimum cooling of the electronics through convection. "From below" is relative to the acceleration of gravity.




Fig. 22: Recommended distances for standard installation position

Compliance with the distances shown in Fig. *Recommended distances for standard installation position* is recommended. The recommended minimum distances should not be regarded as restricted areas for other components. The customer is responsible for verifying compliance with the environmental conditions described in the technical data. Additional cooling measures must be provided, if required.



**Other installation positions**

All other installation positions are characterized by a different spatial position of the signal distribution board, see Fig. *Other installation positions*.

The minimum distances to ambient specified above also apply to these installation positions.




Fig. 23: Other installation positions

## 5.4 Codings

### 5.4.1 Color coding




Fig. 24: EJ modules color code; sample: EJ1809

The EJ modules are color-coded for a better overview in the control cabinet (see diagram above). The color code indicates the signal type. The following table provides an overview of the signal types with corresponding color coding.

Signal type	Modules	Color
Coupler	EJ11xx	No color coding
Digital input	EJ1xxx	Yellow
Digital output	EJ2xxx	Red
Analog input	EJ3xxx	Green
Analog output	EJ4xxx	Blue
Position measurement	EJ5xxx	grey
Communication	EJ6xxx	grey
Motion	EJ7xxx	orange
System	EJ9xxx	grey



### 5.4.2 Mechanical position coding

The modules have two signal-specific coding pins on the underside (see Figs. B1 and B2 below). In conjunction with the coding holes in the signal distribution board (see Figs. A1 and A2 below), the coding pins provide an option for mechanical protection against incorrect connection. This significantly reduces the risk of error during installation and service.

Couplers and placeholder modules have no coding pins.




Fig. 25: Mechanical position coding with coding pins (B1 and B2) and coding holes (A1 and A2)

The following diagram shows the position of the position coding with position numbers on the left-hand side. Modules with the same signal type have the same coding. For sample, all digital input modules have the coding pins at positions one and three. There is no plug protection between modules with the same signal type. During installation the module type should therefore be verified based on the device name.




Fig. 26: Pin coding; sample: digital input modules

## 5.5 Installation on the signal distribution board

EJ modules are installed on the signal distribution board. The electrical connections between coupler and EJ modules are realized via the pin contacts and the signal distribution board.

The EJ components must be installed in a control cabinet or enclosure which must provide protection against fire hazards, environmental conditions and mechanical impact.

### ⚠ WARNING

#### Risk of injury through electric shock and damage to the device!

Bring the module system into a safe, de-energized state before starting installation, disassembly or wiring of the modules.

### NOTE

#### Risk of damage to components through electrostatic discharge!

Observe the regulations for ESD protection.




Fig. 27: Installation of EJ modules

A1 / A2	Latching lugs top / bottom	C1 / C2	Mounting holes
B1 / B2	Coding pins	D1 / D2	Coding holes

To install the modules on the signal distribution board proceed as follows:

1. Before the installation, ensure that the signal distribution board is securely connected to the mounting surface. Installation on an unsecured signal distribution board may result in damage to the board.
2. If necessary, check whether the positions of the coding pins (B) match the corresponding holes in the signal distribution board (D).
3. Compare the device name on the module with the information in the installation drawing.
4. Press the upper and the lower mounting tabs simultaneously and push the module onto the board while gently moving it up and down, until the module is latched securely.  
The required contact pressure can only be established and the maximum current carrying capacity ensured if the module is latched securely.
5. Use placeholder modules (EJ9001) to fill gaps in the module strand.

**NOTE**

- During installation ensure safe latching of the modules on the signal distribution board! The consequences of inadequate contact pressure include:
  - ⇒ loss of quality of the transferred signals,
  - ⇒ increased power dissipation of the contacts,
  - ⇒ impairment of the service life.

## 5.6 Extension options

Three options are available for modifications and extensions of the EJ system.

- Replacing the placeholder modules with the function modules provided for the respective slot
- Assigning function modules specified for the respective slots for the reserve slots at the end of the module string
- Linking with EtherCAT Terminals and EtherCAT Box modules via an Ethernet/EtherCAT connection

### 5.6.1 Using placeholder modules for unused slots

The EJ9001 placeholder modules are used to close temporary gaps in the module strands (see Fig. A1 below). Gaps in the module strand cause interruption in EtherCAT communication and must be equipped with placeholder modules.

In contrast to the passive terminals of the EL series, the placeholder modules actively participate in the data exchange. Several placeholder modules can therefore be connected in series, without impairing the data exchange.

Unused slots at the end of the module strand can be left as reserve slots (see Fig. B1 below).

The machine complexity is extended (extended version) by allocating unused slots (see Figs. A2 below - Exchanging placeholder modules and B2 - Assigning reserve slots) according to the specifications for the signal distribution board.




Fig. 28: Sample: Exchanging placeholder modules and assigning reserve slots

#### **i** E-bus supply

Exchange the placeholder modules with other modules changes the current input from the E-Bus. Ensure that adequate power supply is provided.

### 5.6.2 Linking with EtherCAT Terminals and EtherCAT Box modules via an Ethernet/EtherCAT connection




Fig. 29: Example of extension via an Ethernet/EtherCAT connection



## 5.7 IPC integration

### Connection of CX and EL terminals via the EK1110-004x EtherCAT EJ Coupler

The EK1110-0043 and EK1110-0044 EtherCAT EJ couplers connect the compact DIN-rail PCs of the CX series and attached EtherCAT terminals (ELxxxx) with the EJ modules on the signal distribution board.

The EK1110-004x are supplied from the power supply unit of the Embedded PC.

The E-bus signals and the supply voltage of the field side  $U_p$  are routed directly to the PCB via a plug connector at the rear of the EtherCAT EJ couplers.

Due to the direct coupling of the Embedded PC and the EL terminals with the EJ modules on the PCB, no EtherCAT extension (EK1110) or EtherCAT coupler (EJ1100) is required.

The Embedded PC can be expanded with EtherCAT terminals that are not yet available in the EJ system, for example.



Fig. 30: Example PCB with Embedded PC, EK1110-0043 and EJxxxx, rear view EK1110-0043

**Connection of C6015 / C6017 via the EJ110x-00xx EtherCAT Coupler**


Thanks to their ultra-compact design and versatile mounting options, the C6015 and C6017 IPCs are ideally suited for connection to an EJ system.

In combination with the ZS5000-0003 mounting set, it is possible to place the C6015 and C6017 IPCs compactly on the signal distribution board.

The EJ system is optimally connected to the IPC via the corresponding EtherCAT cable (see following Fig. [A]).

The IPC can be supplied directly via the signal distribution board using the enclosed power plug (see Fig. [B] below).

**NOTE**



**Positioning on the signal distribution board**

The dimensions and distances for placement and other details can be found in the Design Guide and the documentation for the individual components.

The figure below shows the connection of a C6015 IPC to an EJ system as an example. The components shown are schematic, to illustrate the functionality.



Fig. 31: Example for the connection of a C6015 IPC to an EJ system

## 5.8 Disassembly of the signal distribution board

### ⚠ WARNING

#### Risk of injury through electric shock and damage to the device!

Bring the module system into a safe, de-energized state before starting installation, disassembly or wiring of the modules.

### NOTE

#### Risk of damage to components through electrostatic discharge!

Observe the regulations for ESD protection.

Each module is secured through latching on the distribution board, which has to be released for disassembly.




Fig. 32: Disassembly of EJ modules

To disassemble the module from the signal distribution board proceed as follows:

1. Before disassembly, ensure that the signal distribution board is securely connected to the mounting surface. Disassembly of an unsecured signal distribution board may result in damage to the board.
2. Press the upper and lower mounting tabs simultaneously and pull the module from board while gently moving it up and down.

## 5.9 Disposal



Products marked with a crossed-out wheeled bin shall not be discarded with the normal waste stream. The device is considered as waste electrical and electronic equipment. The national regulations for the disposal of waste electrical and electronic equipment must be observed.



## **6 EtherCAT basics**

Please refer to the [EtherCAT System Documentation](#) for the EtherCAT fieldbus basics.

## 7 Commissioning

### 7.1 Note on documentation for the EL33xx

Detailed documentation on the commissioning of the EJ3318 module is being prepared.

#### NOTE



#### Damage to devices or loss of data

The descriptions and notes on the commissioning of the EL3318 EtherCAT Terminal are transferable to the EJ3318 EtherCAT plug-in module.

Before commissioning, read the detailed description of the process data, operating modes and parameterization in the [EL33xx](#) documentation.

## 8 EJ3318 - Object description and parameterization

---

### ● EtherCAT XML Device Description



The display matches that of the CoE objects from the EtherCAT XML Device Description. We recommend downloading the latest XML file from the download area of the Beckhoff website and installing it according to installation instructions.

---

### ● Parameterization via the CoE list (CAN over EtherCAT)



The EtherCAT device is parameterized via the CoE - Online tab (with a double click on the respective object) or via the Process Data tab (assignment of PDOs). A detailed description can be found in the EtherCAT System-Documentation in chapter "[EtherCAT subscriber configuration](#)"

Please note the general CoE notes in the EtherCAT System Documentation in chapter "[CoE-interface](#)" when using/manipulating the CoE parameters:

- Keep a startup list if components have to be replaced
  - Differentiation between online/offline dictionary, existence of current XML description
  - use "CoE reload" for resetting changes
- 

### Introduction

The CoE overview contains objects for different purposes of use:

- [Objects required for parameterization \[► 44\]](#) and [profile-specific objects \[► 46\]](#) required during commissioning
- [Objects for indicating internal settings \[► 48\]](#) (may be fixed)

The following section first describes the objects required for normal operation, followed by a complete overview of missing objects.

## 8.1 Restore object

### Index 1011 Restore default parameters

Index (hex)	Name	Meaning	Data type	Flags	Default
1011:0	Restore default parameters	Restore default parameters	UINT8	RO	0x01 (1 <sub>dec</sub> )
1011:01	SubIndex 001	If this object is set to "0x64616F6C" in the set value dialog, all backup objects are reset to their delivery state.	UINT32	RW	0x00000000 (0 <sub>dec</sub> )

## 8.2 Configuration data

### Index 80n0 TC settings for $0 \leq n \leq 7$ (Ch. 1 - 8)

Index (hex)	Name	Meaning	Data type	Flags	Default
80n0:0	TC Settings	Maximum subindex	UINT8	RO	0x1B (27 <sub>dec</sub> )
80n0:01	Enable user scale	User scale is active.	BOOLEAN	RW	0x00 (0 <sub>dec</sub> )
80n0:02	Presentation	0: Signed presentation 1: Absolute value with MSB as sign Signed amount representation 2: High resolution (1/100 C°)	BIT3	RW	0x00 (0 <sub>dec</sub> )
80n0:05	Siemens bits	The S5 bits are superimposed on the three low-order bits (value 0x60n0:11) Bit 0 = 1 ("overrange" or "underrange") Bit 1 (not used) Bit 2 (not used)	BOOLEAN	RW	0x00 (0 <sub>dec</sub> )
80n0:06	Enable filter	Enable filter, which makes PLC-cycle-synchronous data exchange unnecessary	BOOLEAN	RW	0x00 (0 <sub>dec</sub> )
80n0:0A	Enable user calibration	Enabling of the user calibration	BOOLEAN	RW	0x00 (0 <sub>dec</sub> )
80n0:0B	Enable vendor calibration	Enabling of the vendor calibration	BOOLEAN	RW	0x01 (1 <sub>dec</sub> )
80n0:0C	Coldjunction compensation	0: internal 1: no Cold junction compensation is not active 2: Extern process data Cold junction compensation takes place via the process data (resolution [1/10]°C)	BIT2	RW	0x00 (0 <sub>dec</sub> )
80n0:11	User scale offset	User scaling offset	INT16	RW	0x0000 (0 <sub>dec</sub> )
80n0:12	User scale gain	This is the user scaling gain. The gain is represented in fixed-point format, with the factor $2^{-16}$ . The value 1 corresponds to 65535 (0x00010000).	INT32	RW	0x00010000 (65536 <sub>dec</sub> )
80n0:15	Filter settings	This object determines the digital filter settings, if it is active via Enable filter (index 80n0:06). The possible settings are sequentially numbered. 0: 50 Hz 1: 60 Hz 2: 100 Hz 3: 500 Hz 4: 1 kHz 5: 2 kHz 6: 3.75 kHz 7: 7.5 kHz 8: 15 kHz 9: 30 kHz 10: 5 Hz 11: 10 Hz	UINT16	RW	0x0000 (0 <sub>dec</sub> )

Index (hex)	Name	Meaning	Data type	Flags	Default
80n0:17	User calibration offset	User offset calibration	UINT16	RW	0x0000 (0 <sub>dec</sub> )
80n0:18	User calibration gain	User gain compensation	UINT16	RW	0xFFFF (65535 <sub>dec</sub> )
80n0:19	TC element	Thermocouple Implemented temperature range  0: K, -200°C to 1370°C 1: J, -100°C to 1200°C 2: L, 0°C to 900°C 3: E, -100°C to 1000°C 4: T, -200°C to 400°C 5: N, -100°C to 1300°C 6: U, 0°C to 600 °C 7: B, 200°C to 1820°C 8: R, -50°C to 1767°C 9: S, -50°C to 1766°C 10: C, 0°C to 2320°C 100: +/-30mV (1µV resolution) 101: +/-60mV (2µV resolution) 102: +/-75mV (4µV resolution)	UINT16	RW	0x0000 (0 <sub>dec</sub> )

**i** The filter characteristics are set via index **0x8000:15 [▶ 44]**

The filter frequencies are set for all channels of the module centrally via index 0x8000:15 (channel 1). All other corresponding indices 0x80n0:15 have no parameterization function! The latest firmware version (see status table) returns an EtherCAT-compliant error message, if the filter characteristics of other channels (index 0x80n0:06, 0x80n0:15) are set.

**Index 8080 RTD Settings Ch. 1**

Index (hex)	Name	Bedeutung	Datentyp	Flags	Default
8080:0	RTD Settings Ch1.	Maximum subindex	UINT8	RO	0x1B (27 <sub>dec</sub> )
8080:19	RTD element	RTD element  2: PT1000 (-200...850°C) 8: 1/16 Ohm resolution (0..4059 Ohm)	BOOLEAN	RW	0x02 (2 <sub>dec</sub> )
8080:1A	Connection technology	Permitted values  0: Two-wire connection 3: not connected	BIT3	RW	0x00 (0 <sub>dec</sub> )
8080:1B	Wire calibration 1/32 Ohm	Offset-value for calibration of supply lines [1/32] Ohm	INT16	RW	0x0000 (0 <sub>dec</sub> )

**Index 8090 RTD Settings Ch. 2**

Index (hex)	Name	Bedeutung	Datentyp	Flags	Default
8090:0	RTD Settings Ch2.	Maximum subindex	UINT8	RO	0x1B (27 <sub>dec</sub> )
8090:19	RTD element	RTD element  2: PT1000 (-200...850°C) 8: 1/16 Ohm resolution (0..4059 Ohm)	BOOLEAN	RW	0x02 (2 <sub>dec</sub> )
8090:1A	Connection technology	Permitted values  0: Two-wire connection 3: not connected	BIT3	RW	0x00 (0 <sub>dec</sub> )
8090:1B	Wire calibration 1/32 Ohm	Offset-value for calibration of supply lines [1/32] Ohm	INT16	RW	0x0000 (0 <sub>dec</sub> )

**8.3 Profile-specific objects (0x6000-0xFFFF)**

The profile-specific objects have the same meaning for all EtherCAT slaves that support the profile 5001.

## 8.4 Input data

### Index 60n0 TC Inputs for $0 \leq n \leq 7$ (Ch. 1 - 8)

Index (hex)	Name	Meaning	Data type	Flags	Default
60n0:0	TC Inputs Ch.n	Maximum subindex	UINT8	RO	0x11 (17 <sub>dec</sub> )
60n0:01	Underrange	The measuring range is undershot.	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
60n0:02	Overrange	The measuring range is overshot. ("open circuit" detection if "error" [index 0x60n0:07]) is set	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
60n0:07	Error	The error bit is set if the data is invalid.	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
60n0:0F	TxPDO State	Validity of the data of the associated TxPDO (0 = valid, 1 = invalid).	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
60n0:10	TxPDO Toggle	The TxPDO toggle is toggled by the slave when the data of the associated TxPDO is updated.	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
60n0:11	Value	The analog input data	INT16	RO	0x0000 (0 <sub>dec</sub> )

### Index 6080 RTD Inputs Ch. 1

Index (hex)	Name	Meaning	Data type	Flags	Default
6080:0	RTD Inputs Ch.1	Maximum subindex	UINT8	RO	0x11 (17 <sub>dec</sub> )
6080:01	Underrange	The measuring range is undershot.	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
6080:02	Overrange	The measuring range is overshot. ("open circuit" detection if "error" [index 0x60n0:07]) is set	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
6080:07	Error	The error bit is set if the data is invalid.	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
6080:0F	TxPDO State	Validity of the data of the associated TxPDO (0 = valid, 1 = invalid).	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
6080:10	TxPDO Toggle	The TxPDO toggle is toggled by the slave when the data of the associated TxPDO is updated.	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
6080:11	Value	The analog input data	INT16	RO	0x0000 (0 <sub>dec</sub> )

### Index 6090 RTD Inputs Ch. 2

Index (hex)	Name	Meaning	Data type	Flags	Default
6090:0	RTD Inputs Ch.2	Maximum subindex	UINT8	RO	0x11 (17 <sub>dec</sub> )
6090:01	Underrange	The measuring range is undershot.	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
6090:02	Overrange	The measuring range is overshot. ("open circuit" detection if "error" [index 0x60n0:07]) is set	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
6090:07	Error	The error bit is set if the data is invalid.	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
6090:0F	TxPDO State	Validity of the data of the associated TxPDO (0 = valid, 1 = invalid).	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
6090:10	TxPDO Toggle	The TxPDO toggle is toggled by the slave when the data of the associated TxPDO is updated.	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )
6090:11	Value	The analog input data	INT16	RO	0x0000 (0 <sub>dec</sub> )

## 8.5 Output data

### Index 70n0 TC Outputs for $0 \leq n \leq 7$ (Ch. 1 - 8)

Index (hex)	Name	Meaning	Data type	Flags	Default value
70n0:0	TC Outputs Chn.	Maximum subindex	UINT8	RO	0x11 (17 <sub>dec</sub> )
70n0:11	CJCompensation	Temperature of the cold junction (resolution in 1/10 °C) (index 0x80n0:0C [▶ 44]), comparison via the process data)	INT16	RO	0x0000 (0 <sub>dec</sub> )

## 8.6 Configuration data vendor specific

### Index 80nF TC Vendor data for $0 \leq n \leq 7$ (Ch. 1 - 8)

Index (hex)	Name	Meaning	Data type	Flags	Default
80nF:0	TC Vendor data Ch.n	Maximum subindex	UINT8	RO	0x02 (2 <sub>dec</sub> )
80nF:01	Calibration offset	Manufacturer calibration offset	INT16	RW	0x0000 (0 <sub>dec</sub> )
80nF:02	Calibration gain	Manufacturer calibration gain	UINT16	RW	0x9E50 (40528 <sub>dec</sub> )

### Index 808F RTD Vendor data Ch. 1

Index (hex)	Name	Meaning	Data type	Flags	Default
808F:0	RTD Vendor data Ch.1	Maximum subindex	UINT8	RO	0x04 (4 <sub>dec</sub> )
808F:03	Calibration offset Pt1000	Manufacturer calibration offset Pt1000	INT16	RW	-
808F:04	Calibration gain Pt1000	Manufacturer calibration gain Pt1000	UINT16	RW	-

### Index 809F RTD Vendor data Ch. 2

Index (hex)	Name	Meaning	Data type	Flags	Default
809F:0	RTD Vendor data Ch.2	Maximum subindex	UINT8	RO	0x04 (4 <sub>dec</sub> )
809F:03	Calibration offset Pt1000	Manufacturer calibration offset Pt1000	INT16	RW	-
809F:04	Calibration gain Pt1000	Manufacturer calibration gain Pt1000	UINT16	RW	-

## 8.7 Information and diagnostic data

### Index 80nE TC Internal data for $0 \leq n \leq 7$ (Ch. 1 - 8)

Index (hex)	Name	Meaning	Data type	Flags	Default
80nE:0	TC Internal data Ch.n	Maximum subindex	UINT8	RO	0x05 (5 <sub>dec</sub> )
80nE:01	ADC raw value TC	ADC raw value thermocouple	INT32	RO	0x00000000 (0 <sub>dec</sub> )
80nE:03	CJ temperature	Cold junction temperature (resolution [1/10]°C)	INT16	RO	0x0000 (0 <sub>dec</sub> )
80nE:04	CJ voltage	Cold junction voltage (resolution 1 µV)	INT32	RO	0x00000000 (0 <sub>dec</sub> )
80nE:05	CJ resistor	reserved	UINT16	RO	0x0000 (0 <sub>dec</sub> )

### Index 808E RTD Internal data Ch. 1

Index (hex)	Name	Meaning	Data type	Flags	Default
808E:0	RTD Internal data Ch.1	Maximum subindex	UINT8	RO	0x04 (4 <sub>dec</sub> )
808E:01	ADC raw value	ADC raw value	INT32	RO	0x00000000 (0 <sub>dec</sub> )
808E:02	Resistor	Resistance (measured value of resistance sensor, resolution 1/256 Ohm)	UINT32	RO	0x00000000 (0 <sub>dec</sub> )

### Index 809E RTD Internal data Ch. 2

Index (hex)	Name	Meaning	Data type	Flags	Default
809E:0	RTD Internal data Ch.2	Maximum subindex	UINT8	RO	0x04 (4 <sub>dec</sub> )
809E:01	ADC raw value	ADC raw value	INT32	RO	0x00000000 (0 <sub>dec</sub> )
809E:02	Resistor	Resistance (measured value of resistance sensor, resolution 1/256 Ohm)	UINT32	RO	0x00000000 (0 <sub>dec</sub> )

**Index F000 Modular device profile**

Index (hex)	Name	Meaning	Data type	Flags	Default
F000:0	Modular device profile	General information for the modular device profile	UINT8	RO	0x02 (2 <sub>dec</sub> )
F000:01	Module index distance	Index spacing of the objects of the individual channels	UINT16	RO	0x0010 (16 <sub>dec</sub> )
F000:02	Maximum number of modules	Number of channels	UINT16	RO	0x000A (10 <sub>dec</sub> )

**Index F008 Code word**

Index (hex)	Name	Meaning	Data type	Flags	Default
F008:0	Code word	currently reserved	UINT32	RW	0x00000000 (0 <sub>dec</sub> )

**Index F010 Module list**

Index (hex)	Name	Meaning	Data type	Flags	Default
F010:0	Module list	Maximum subindex	UINT8	RO	0x0A (10 <sub>dec</sub> )
F010:01	Subindex 001	Profile 330	INT32	RO	0x0000014A (330 <sub>dec</sub> )
F010:02	Subindex 002	Profile 330	INT32	RO	0x0000014A (330 <sub>dec</sub> )
F010:03	Subindex 003	Profile 330	INT32	RO	0x0000014A (330 <sub>dec</sub> )
F010:04	Subindex 004	Profile 330	INT32	RO	0x0000014A (330 <sub>dec</sub> )
F010:05	Subindex 005	Profile 330	INT32	RO	0x0000014A (330 <sub>dec</sub> )
F010:06	Subindex 006	Profile 330	INT32	RO	0x0000014A (330 <sub>dec</sub> )
F010:07	Subindex 007	Profile 330	INT32	RO	0x0000014A (330 <sub>dec</sub> )
F010:08	Subindex 008	Profile 330	INT32	RO	0x0000014A (330 <sub>dec</sub> )
F010:09	Subindex 009	Profile 320	INT32	RO	0x00000140 (320 <sub>dec</sub> )
F010:0A	Subindex 010	Profile 320	INT32	RO	0x00000140 (320 <sub>dec</sub> )

## 8.8 Standard objects (0x1000-0x1FFF)

The standard objects have the same meaning for all EtherCAT slaves.

**Index 1000 Device type**

Index (hex)	Name	Meaning	Data type	Flags	Default value
1000:0	Device type	Device type of the EtherCAT slave: the Lo-Word contains the CoE profile used (5001). The Hi-Word contains the module profile according to the modular device profile.	UINT32	RO	0x00001389 (5001 <sub>dec</sub> )

**Index 1008 Device name**

Index (hex)	Name	Meaning	Data type	Flags	Default value
1008:0	Device name	Device name of the EtherCAT slave	STRING	RO	EJ3318

**Index 1009 Hardware version**

Index (hex)	Name	Meaning	Data type	Flags	Default
1009:0	Hardware version	Hardware version of the EtherCAT slave	STRING	RO	00



**Index 100A Software version**

Index (hex)	Name	Meaning	Data type	Flags	Default
100A:0	Software version	Firmware version of the EtherCAT slave	STRING	RO	01

**Index 1018 Identity**

Index (hex)	Name	Meaning	Data type	Flags	Default
1018:0	Identity	Information for identifying the slave	UINT8	RO	0x04 (4 <sub>dec</sub> )
1018:01	Vendor ID	Vendor ID of the EtherCAT slave	UINT32	RO	0x00000002 (2 <sub>dec</sub> )
1018:02	Product code	Product code of the EtherCAT slave	UINT32	RO	(0x0CF62852) (217458770 <sub>dez</sub> )
1018:03	Revision	Revision number of the EtherCAT slave; the low word (bit 0-15) indicates the special terminal number, the high word (bit 16-31) refers to the device description	UINT32	RO	( )
1018:04	Serial number	Serial number of the EtherCAT slave; the low byte (bit 0-7) of the low word contains the year of production, the high byte (bit 8-15) of the low word contains the week of production, the high word (bit 16-31) is 0	UINT32	RO	( )

**Index 10F0 Backup parameter handling**

Index (hex)	Name	Meaning	Data type	Flags	Default
10F0:0	Backup parameter handling	Information for standardized loading and saving of backup entries	UINT8	RO	0x01 (1 <sub>dec</sub> )
10F0:01	Checksum	Checksum across all backup entries of the EtherCAT slave	UINT32	RO	0x00000000 (0 <sub>dec</sub> )

**Index 160n TC RxPDO-Map für 0 ≤ n ≤ 7 (Ch. 1 - 8)**

Index (hex)	Name	Meaning	Data type	Flags	Default
160n:0	TC RxPDO-Map Ch.n	PDO Mapping RxPDO n+1	UINT8	RW	0x01 (1 <sub>dez</sub> )
160n:01	SubIndex 001	n. PDO Mapping entry (object 0x70n0 (TC Outputs Ch.n+1), entry 0x11 (CJCompensation))	UINT32	RW	0x70n0:11, 16

**Index 1A0n TC TxPDO Map for 0 ≤ n ≤ 7 (Ch. 1 - 8)**

Index (hex)	Name	Meaning	Data type	Flags	Default
1A0n:0	TC TxPDO Map Ch.n	PDO Mapping TxPDO 1	UINT8	RW	0x08 (8 <sub>dec</sub> )
1A0n:01	SubIndex 001	1. PDO Mapping entry (object 0x60n0 (TC Inputs Ch.n+1), entry 0x01 (Underrange))	UINT32	RW	0x60n0:01, 1
1A0n:02	SubIndex 002	2. PDO Mapping entry (object 0x60n0 (TC Inputs Ch.n+1), entry 0x02 (Overrange))	UINT32	RW	0x60n0:02, 1
1A0n:03	SubIndex 003	3. PDO Mapping entry (4 bits align)	UINT32	RW	0x0000:00, 4
1A0n:04	SubIndex 004	4. PDO Mapping entry (object 0x60n0 (TC Inputs Ch.n+1), entry 0x07 (Error))	UINT32	RW	0x60n0:07, 1
1A0n:05	SubIndex 005	5. PDO Mapping entry (7 bits align)	UINT32	RW	0x0000:00, 7
1A0n:06	SubIndex 006	6. PDO Mapping entry (object 0x60n0 (TC Inputs Ch.n+1), entry 0x0F (TxPDO-State))	UINT32	RW	0x60n0:0F, 1
1A0n:07	SubIndex 007	7. PDO Mapping entry (object 0x60n0 (TC Inputs Ch.n+1), entry 0x10 (TxPDO-Toggle))	UINT32	RW	0x60n0:10, 1
1A0n:08	SubIndex 008	8. PDO Mapping entry (object 0x60n0 (TC Inputs Ch.n+1), entry 0x11 (Value))	UINT32	RW	0x60n0:11, 16

**Index 1A08 RTD TxPDO-Map Inputs Ch.1**

Index (hex)	Name	Meaning	Data type	Flags	Default
1A08:0	RTD TxPDO Map-Inputs Ch.1	PDO Mapping TxPDO 1	UINT8	RW	0x08 (8 <sub>dec</sub> )
1A08:01	SubIndex 001	1. PDO Mapping entry (object 0x6080 (RTD Inputs Ch.1), entry 0x01 (Underrange))	UINT32	RW	0x6080:01, 1
1A08:02	SubIndex 002	2. PDO Mapping entry (object 0x6080 (RTD Inputs Ch.1), entry 0x02 (Overrange))	UINT32	RW	0x6080:02, 1
1A08:03	SubIndex 003	3. PDO Mapping entry (4 bits align)	UINT32	RW	0x0000:00, 4
1A08:04	SubIndex 004	4. PDO Mapping entry (object 0x6080 (RTD Inputs Ch.1), entry 0x07 (Error))	UINT32	RW	0x6080:07, 1
1A08:05	SubIndex 005	5. PDO Mapping entry (7 bits align)	UINT32	RW	0x0000:00, 7
1A08:06	SubIndex 006	6. PDO Mapping entry (object 0x6080 (RTD Inputs Ch.1), entry 0x0F (TxPDO-State))	UINT32	RW	0x6080:0F, 1
1A08:07	SubIndex 007	7. PDO Mapping entry (object 0x6080 (RTD Inputs Ch.1), entry 0x10 (TxPDO-Toggle))	UINT32	RW	0x6080:10, 1
1A08:08	SubIndex 008	8. PDO Mapping entry (object 0x6080 (RTD Inputs Ch.1) entry 0x11 (Value))	UINT32	RW	0x6080:11, 16

**Index 1A09 RTD TxPDO-Map Inputs Ch.2**

Index (hex)	Name	Meaning	Data type	Flags	Default
1A09:0	RTD TxPDO Map-Inputs Ch.1	PDO Mapping TxPDO 1	UINT8	RW	0x08 (8 <sub>dec</sub> )
1A09:01	SubIndex 001	1. PDO Mapping entry (object 0x6090 (RTD Inputs Ch.2), entry 0x01 (Underrange))	UINT32	RW	0x6090:01, 1
1A09:02	SubIndex 002	2. PDO Mapping entry (object 0x6090 (RTD Inputs Ch.2), entry 0x02 (Overrange))	UINT32	RW	0x6090:02, 1
1A09:03	SubIndex 003	3. PDO Mapping entry (4 bits align)	UINT32	RW	0x0000:00, 4
1A09:04	SubIndex 004	4. PDO Mapping entry (object 0x6090 (RTD Inputs Ch.2), entry 0x07 (Error))	UINT32	RW	0x6090:07, 1
1A09:05	SubIndex 005	5. PDO Mapping entry (7 bits align)	UINT32	RW	0x0000:00, 7
1A09:06	SubIndex 006	6. PDO Mapping entry (object 0x6090 (RTD Inputs Ch.2), entry 0x0F (TxPDO-State))	UINT32	RW	0x6090:0F, 1
1A09:07	SubIndex 007	7. PDO Mapping entry (object 0x6090 (RTD Inputs Ch.2), entry 0x10 (TxPDO-Toggle))	UINT32	RW	0x6090:10, 1
1A09:08	SubIndex 008	8. PDO Mapping entry (object 0x6090 (RTD Inputs Ch.2), entry 0x11 (Value))	UINT32	RW	0x6090:11, 16

**Index 1C00 Sync manager type**

Index (hex)	Name	Meaning	Data type	Flags	Default
1C00:0	Sync manager type	Using the Sync Managers	UINT8	RO	0x04 (4 <sub>dec</sub> )
1C00:01	SubIndex 001	Sync-Manager Type Channel 1: Mailbox Write	UINT8	RO	0x01 (1 <sub>dec</sub> )
1C00:02	SubIndex 002	Sync-Manager Type Channel 2: Mailbox Read	UINT8	RO	0x02 (2 <sub>dec</sub> )
1C00:03	SubIndex 003	Sync-Manager Type Channel 3: Process Data Write (Outputs)	UINT8	RO	0x03 (3 <sub>dec</sub> )
1C00:04	SubIndex 004	Sync-Manager Type Channel 4: Process Data Read (Inputs)	UINT8	RO	0x04 (4 <sub>dec</sub> )

**Index 1C12 RxPDO assign**

Index (hex)	Name	Meaning	Data type	Flags	Default
1C12:0	RxPDO assign	PDO Assign Outputs	UINT8	RW	0x00 (0 <sub>dec</sub> )

**Index 1C13 TxPDO assign**

Index (hex)	Name	Meaning	Data type	Flags	Default
1C13:0	TxPDO assign	PDO Assign Inputs	UINT8	RW	0x0A (10 <sub>dec</sub> )
1C13:01	Subindex 001	1. allocated TxPDO (contains the index of the associated TxPDO mapping object)	UINT16	RW	0x1A00 (6656 <sub>dec</sub> )
1C13:02	Subindex 002	2. allocated TxPDO (contains the index of the associated TxPDO mapping object)	UINT16	RW	0x1A01 (6657 <sub>dec</sub> )
1C13:03	Subindex 003	3. allocated TxPDO (contains the index of the associated TxPDO mapping object)	UINT16	RW	0x1A02 (6658 <sub>dec</sub> )
1C13:04	Subindex 004	4. allocated TxPDO (contains the index of the associated TxPDO mapping object)	UINT16	RW	0x1A03 (6659 <sub>dec</sub> )
1C13:05	Subindex 005	5. allocated TxPDO (contains the index of the associated TxPDO mapping object)	UINT16	RW	0x1A04 (6660 <sub>dec</sub> )
1C32:06	Subindex 006	6. allocated TxPDO (contains the index of the associated TxPDO mapping object)	UINT16	RW	0x1A05 (6661 <sub>dec</sub> )
1C13:07	Subindex 007	7. allocated TxPDO (contains the index of the associated TxPDO mapping object)	UINT16	RW	0x1A06 (6662 <sub>dec</sub> )
1C13:08	Subindex 008	8. allocated TxPDO (contains the index of the associated TxPDO mapping object)	UINT16	RW	0x1A07 (6663 <sub>dec</sub> )
1C13:09	Subindex 009	9. allocated TxPDO (contains the index of the associated TxPDO mapping object)	UINT16	RW	0x1A08 (6664 <sub>dec</sub> )
1C13:0A	Subindex 010	10. allocated TxPDO (contains the index of the associated TxPDO mapping object)	UINT16	RW	0x1A09 (6665 <sub>dec</sub> )

## Index 1C32 SM output parameter

Index (hex)	Name	Meaning	Data type	Flags	Default
1C32:0	SM output parameter	Synchronization parameters for the outputs	UINT8	RO	0x20 (32 <sub>dec</sub> )
1C32:01	Sync mode	Current synchronization mode: <ul style="list-style-type: none"> <li>• 0: Free Run</li> <li>• 1: Synchronous with SM 2 event</li> <li>• 2: DC - Synchronous with SYNC0 Event</li> <li>• 3: DC - Synchronous with SYNC1 Event</li> </ul>	UINT16	RW	0x0000 (0 <sub>dec</sub> )
1C32:02	Cycle time	Cycle time (in ns): <ul style="list-style-type: none"> <li>• Free Run: Cycle time of the local timer</li> <li>• Synchronous with SM 2 event: Master cycle time</li> <li>• DC-Mode: SYNC0/SYNC1 Cycle Time</li> </ul>	UINT32	RW	0x00000000 (0 <sub>dec</sub> )
1C32:03	Shift time	Time between SYNC0 event and reading of the inputs (in ns, only DC mode)	UINT32	RW	0x00000000 (0 <sub>dec</sub> )
1C32:04	Sync modes supported	Supported synchronization modes: <ul style="list-style-type: none"> <li>• Bit 0: free run is supported</li> <li>• Bit 1: synchronous with SM 2 event is supported (outputs available)</li> <li>• Bit 1: synchronous with SM 3 event is supported (no outputs available)</li> <li>• Bit 2-3 = 01: DC mode is supported</li> <li>• Bit 4-5 = 01: output shift with SYNC1 event (only DC mode)</li> <li>• Bit 14 = 1: dynamic times (measurement through writing of 0x1C32:08)</li> </ul>	UINT16	RO	0xC001 (49153 <sub>dec</sub> )
1C32:05	Minimum cycle time	Minimum cycle time (in ns)	UINT32	RO	0x00000000 (0 <sub>dec</sub> )
1C32:06	Calc and copy time	Minimum time between SYNC0 and SYNC1 Event (in ns, DC mode only)	UINT32	RO	0x00000000 (0 <sub>dec</sub> )
1C32:07	Minimum delay time	Minimum time between SYNC1 event and output of the outputs (in ns, only DC mode) 0 because DC mode is not supported by EJ3318	UINT32	RO	0x00000000 (0 <sub>dec</sub> )
1C32:08	Command	<ul style="list-style-type: none"> <li>• 0: Measurement of the local cycle time is stopped</li> <li>• 1: Measurement of the local cycle time is started</li> </ul> <p>The entries 0x1C32:03, 0x1C32:05, 0x1C32:06, 0x1C32:09, 0x1C33:03, 0x1C33:06, 0x1C33:09 [► 53] are updated with the maximum measured values. For a subsequent measurement the measured values are reset</p>	UINT16	RW	0x0000 (0 <sub>dec</sub> )
1C32:09	Maximum delay time	Time between SYNC1 event and reading of the outputs (in ns, only DC mode)	UINT32	RO	0x00000000 (0 <sub>dec</sub> )
1C32:0B	SM event missed counter	Number of missed SM events in OPERATIONAL (DC mode only)	UINT16	RO	0x0000 (0 <sub>dec</sub> )
1C32:0C	Cycle exceeded counter	Number of occasions the cycle time was exceeded in OPERATIONAL (cycle was not completed in time or the next cycle began too early)	UINT16	RO	0x0000 (0 <sub>dec</sub> )
1C32:0D	Shift too short counter	Number of occasions that the interval between SYNC0 and SYNC1 event was too short (DC mode only)	UINT16	RO	0x0000 (0 <sub>dec</sub> )
1C32:20	Sync error	The synchronization was not correct in the last cycle (outputs were output too late; DC mode only)	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )

**Index 1C33 SM input parameter**

Index (hex)	Name	Meaning	Data type	Flags	Default
1C33:0	SM input parameter	Synchronization parameters for the inputs	UINT8	RO	0x20 (32 <sub>dec</sub> )
1C33:01	Sync mode	Current synchronization mode: <ul style="list-style-type: none"> <li>• 0: Free Run</li> <li>• 1: Synchronous with SM 3 event (no outputs available)</li> <li>• 2: DC - Synchronous with SYNC0 Event</li> <li>• 3: DC - Synchronous with SYNC1 Event</li> <li>• 34: Synchronous with SM 2 event (outputs available)</li> </ul>	UINT16	RW	0x0000 (0 <sub>dec</sub> )
1C33:02	Cycle time	Cycle time (in ns): <ul style="list-style-type: none"> <li>• Free Run: Cycle time of the local timer</li> <li>• Synchronous with SM 2 event: Master cycle time</li> <li>• DC-Mode: SYNC0/SYNC1 Cycle Time</li> </ul>	UINT32	RW	0x00000000 (0 <sub>dec</sub> )
1C33:03	Shift time	Time between SYNC0 event and reading of the inputs (in ns, only DC mode)	UINT32	RW	0x00000000 (0 <sub>dec</sub> )
1C33:04	Sync modes supported	Supported synchronization modes: <ul style="list-style-type: none"> <li>• Bit 0: free run is supported</li> <li>• Bit 1: synchronous with SM 2 event is supported (outputs available)</li> <li>• Bit 1: synchronous with SM 3 event is supported (no outputs available)</li> <li>• Bit 2-3 = 01: DC mode is supported</li> <li>• Bit 4-5 = 01: input shift through local event (outputs available)</li> <li>• Bit 4-5 = 10: input shift with SYNC1 event (no outputs available)</li> <li>• Bit 14 = 1: dynamic times (measurement through writing of 0x1C32:08 [► 52] or 0x1C33:08)</li> </ul>	UINT16	RO	0xC001 (49153 <sub>dec</sub> )
1C33:05	Minimum cycle time	Minimum cycle time (in ns)	UINT32	RO	0x00000000 (0 <sub>dec</sub> )
1C33:06	Calc and copy time	Time between reading of the inputs and availability of the inputs for the master (in ns, only DC mode)	UINT32	RO	0x00000000 (0 <sub>dec</sub> )
1C33:07	Minimum delay time	Minimum time between Sync-1 Event and reading of the inputs (in ns, only DC mode)  0 because DC mode is not supported by EJ3318			
1C33:08	Command	<ul style="list-style-type: none"> <li>• 0: Measurement of the local cycle time is stopped</li> <li>• 1: Measurement of the local cycle time is started</li> </ul> <p>The entries 0x1C32:03, 0x1C32:05, 0x1C32:06, 0x1C32:09 [► 52], 0x1C33:03, 0x1C33:06, 0x1C33:09 are updated with the maximum measured values.. For a subsequent measurement the measured values are reset</p>	UINT16	RW	0x0000 (0 <sub>dec</sub> )
1C33:09	Maximum delay time	Time between SYNC1 event and reading of the inputs (in ns, only DC mode)	UINT32	RO	0x00000000 (0 <sub>dec</sub> )
1C33:0B	SM event missed counter	Number of missed SM events in OPERATIONAL (DC mode only)	UINT16	RO	0x0000 (0 <sub>dec</sub> )
1C33:0C	Cycle exceeded counter	Number of occasions the cycle time was exceeded in OPERATIONAL (cycle was not completed in time or the next cycle began too early)	UINT16	RO	0x0000 (0 <sub>dec</sub> )
1C33:0D	Shift too short counter	Number of occasions that the interval between SYNC0 and SYNC1 event was too short (DC mode only)	UINT16	RO	0x0000 (0 <sub>dec</sub> )
1C33:20	Sync error	The synchronization was not correct in the last cycle (outputs were output too late; DC mode only)	BOOLEAN	RO	0x00 (0 <sub>dec</sub> )

## 9 Appendix

### 9.1 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

#### **Beckhoff's branch offices and representatives**

Please contact your Beckhoff branch office or representative for local support and service on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on her internet pages: <https://www.beckhoff.com>

You will also find further documentation for Beckhoff components there.

#### **Beckhoff Support**

Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

Hotline: +49 5246 963 157  
Fax: +49 5246 963 9157  
e-mail: [support@beckhoff.com](mailto:support@beckhoff.com)

#### **Beckhoff Service**

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: +49 5246 963 460  
Fax: +49 5246 963 479  
e-mail: [service@beckhoff.com](mailto:service@beckhoff.com)

#### **Beckhoff Headquarters**

Beckhoff Automation GmbH & Co. KG

Huelshorstweg 20  
33415 Verl  
Germany

Phone: +49 5246 963 0  
Fax: +49 5246 963 198  
e-mail: [info@beckhoff.com](mailto:info@beckhoff.com)  
web: <https://www.beckhoff.com>



More Information:  
[www.beckhoff.com/EJ3318](http://www.beckhoff.com/EJ3318)

Beckhoff Automation GmbH & Co. KG  
Hülshorstweg 20  
33415 Verl  
Germany  
Phone: +49 5246 9630  
[info@beckhoff.com](mailto:info@beckhoff.com)  
[www.beckhoff.com](http://www.beckhoff.com)

